


# *Vinotemp*

## **WINE-MATE Cooling Unit**

### ***Use & Care Manual***

**WM1500 HTD, HTD-TE  
WM2500 HTD, HTD-TE**



***Vinotemp International Corp.***

[www.winemate.com](http://www.winemate.com)

**READ AND SAVE THESE INSTRUCTIONS**


## Important Safety Information

### **WARNING**



#### To avoid the risk of electrical shock, property damage, personal injury or death:

- The power cord must be plugged into a 3-prong grounding-type wall receptacle, grounded in accordance with the National Electrical Code, ANSI/NFPA 70 - latest edition and local codes and ordinances.
- It is the personal responsibility of the consumer to have a proper 3-prong wall receptacle installed by a qualified electrician.
- **DO NOT, UNDER ANY CIRCUMSTANCES, REMOVE THE POWER CORD GROUNDING PRONG.**
- A separate adequately fused and grounded circuit should be available for this appliance.
- Do not remove any grounding wires from individual components while servicing, unless the component is to be removed and replaced. *It is extremely important to replace all grounding wires when components are replaced.*



### **WARNING**



#### **ELECTRIC SHOCK HAZARD**

- Disconnect electric supply from appliance before servicing.
- Replace all panels before operating.
- Failure to do so could result in death or electrical shock.


- **DO NOT PLUG IN UNTIL 24 HOURS AFTER DELIVERY.**
- **DO NOT USE A GROUND FAULT INTERRUPTER (GFI).**
- **A DEDICATED 15 AMP CIRCUIT IS HIGHLY RECOMMENDED.**

## TABLE OF CONTENTS

<b>Feature Description.....</b>	<b>3</b>
<b>Installation Instruction.....</b>	<b>5</b>
<b>Temperature Control &amp; Humidity Adjustment.....</b>	<b>8</b>
<b>Care Guide.....</b>	<b>11</b>
<b>Troubleshooting.....</b>	<b>13</b>
<b>Wiring Diagram.....</b>	<b>16</b>
<b>Customer Support.....</b>	<b>17</b>
<b>Warranty.....</b>	<b>18</b>


## Feature Description

- WM1500HTD, HTD-TE and WM2500HTD, HTD-TE cooling units are designed and used to provide a subtle temperature between 50~65 °F for suitable space at a normal environment.
- The refrigerated space will maintain humidity of 50~70% RH even when the environment becomes dry and humid.
- These temperatures and humidities are optimized for long term storage of wine.
- Humidity and temperature digital control using patent pending technology
- Optimized air flow for most even temperatures in wine cabinets
- Exchangeable supply grille for front, back and down cold air distribution
- Multiple options for top and rear hot air exhaust
- High efficient tube-axial fans for both condenser and evaporator
- Extra insulation for both thermal and noise isolation
- Unique condensate drain tray for humidity adjustment
- Grill size optimized for easy cleaning and safety
- Stamping ribbed housing for robust structure
- Self-contained ready for use and easy for installation



1. POWER CORD
2. COLD-AIR SUPPLY
3. DIGITAL CONTROLLER
4. RETURN-AIR INTAKE
5. AMBIENT-AIR INTAKE
6. HOT-AIR BACK EXHAUST (OPTIONAL)
7. HOT-AIR TOP EXHAUST

**Fig. 1.1 FEATURE DESCRIPTION**



**Fig. 1.2 DIMENSIONS (in)**

The dimensions and capacity are specified as follows:

Model	Exhaust	Cooling Capacity, CFM 55°F/75°F	Bottle Capacity 55°F/75°F		Electrical	Weight
			cu ft	bottles		
<b>1500htd</b>	Rear Exhaust	1500 Btu/h, 120 CFM	150 cu ft	800 bottles	115V/60Hz 4A	55 lb
<b>1500htd-te</b>	Top Exhaust	1500 Btu/h, 120 CFM	150 cu ft	800 bottles	115V/60Hz 4A	55 lb
<b>2500htd</b>	Rear Exhaust	2500 Btu/h, 180 CFM	250 cu ft	1200 bottles	115V/60Hz 5A	60 lb
<b>2500htd-te</b>	Top Exhaust	2500 Btu/h, 180 CFM	250 cu ft	1200 bottles	115V/60Hz 5A	60 lb

- See the voltage, frequency and current on the nameplate at the cooling unit.

# Installation Instruction

## 1. Cabinet Location

- Place the wine cabinet in a properly ventilated location. Otherwise, heat exhausted by the cooling unit will build up and it will not operate properly.
- The exhaust area must not be closed space and must be ventilated. The ambient temperatures shall not be higher than 90 °F or lower than 50 °F.

### 1) Rear Exhaust Location

- Leave min 6 "clearance from the rear to the wall.
- Leave min 12" clearance from the top to the ceiling.
- Leave min 6" clearance from the left and right sides.

### 2) Front Exhaust Location

- Leave min 6" clearance from the front if left and right sides unobstructed.
- Or, leave min 36" clearance from the front if left and right sides obstructed


### 3) Top Exhaust Location

- Leave min 12" from the top to the ceiling.
- Leave min 2 "clearance from the rear to the wall.
- Leave min 2" clearance from the left and right sides.


### 4) Side Exhaust Location

- Leave min 6 "clearance from the left or right side to the wall.
- Leave min 12" clearance from the top to the ceiling.


## 2. Installation



**Fig. 2.1 COOLING UNIT MOUNTING**



**Fig. 2.2 MOUNTING CUTOUT & GASKET LIPS  
(LOCATED AT THE CABINET)**



**Fig. 2.3 TOP EXHAUST GASKET  
(LOCATED ON THE COOLING UNIT)**

- Cut a rectangular inside opening at the rear of the cabinet with the 1/4" clearance inwards to the width and height of the cooling unit. By not going through, leave 1/2" lip inside at the wall to place the gaskets (see Fig. 2.2).
- If top exhaust, cut another rectangular opening at the top of the cabinet to the length and width of the top exhaust (see Fig.2.2).
- Make 2 holes at the ceiling to install the 1/4 inside diameter wood thread inserts (see Fig.2.2).
- Place the gaskets (1) on the gasket lips (see Fig 2.1).
- If top exhaust, place another gaskets along the top exhaust at the top of the cooling unit (see Fig.2.3).
- Place the cooling unit to a flat and stable place.
- Then move it on the top of the wine rack temporarily.
- Move the cooling unit towards the mounting sides and push to press the gaskets.
- Fasten the 2 brackets and use 7/16" wrench to tighten the 2 screws (see Fig 2.1).
- If top exhaust, install another top exhaust grille at the top of the cabinet.
- Plug the cooling unit in receptacle.
- Plug the wine cabinet.

### **3. Electrical Cord**

- Because of potential safety hazards under a certain condition, we strongly recommend against the use of an extension cord. However, if you still elect to use an extension cord, it is absolutely necessary that it will be a UL LISTED 3-wire grounding type appliance extension cord having a 3-blade grounding plug and a 3-slot receptacle that will plug into the appliance. The marked rating of the extension cord should be 115 V, 15 A.

# Temperature Control & Humidity Adjustment

## 1. Temperature Setting

- Set the temperature at 55 °F for the optimum aging of wine
- On initial start-up, the time required to reach the desired temperature will vary, depending on the quantity of bottles, temperature setting and surrounding temperature.
- Allow 24 hours to stabilize the temperature for each new temperature setting operation

## 2. Use of the controller







Fig. 3.1 DIGITAL CONTROLLER

### 1) Display

During normal operating conditions, the display shows the value measured by the air regulation probe. In case of active alarm, the temperature flashes alternately to the code alarm.


#### 1.1 LED Functions


LED	MODE	FUNCTION
	ON	Compressor enabled
	Flashing	Anti-short cycle delay enabled
	ON	Defrost enabled
	ON	An alarm is occurring
°C/°F	ON	Measurement unit
°C/°F	Flashing	Programming phase


## 1.2 Front Panel Commands

**SET**: To display target set point; in programming mode it selects a parameter or confirm an operation.


 **(DEF)** To start a manual defrost

 **(UP)**: To see the max. stored temperature; in programming mode it browses the parameter codes or increases the displayed value.

 **(DOWN)** To see the min stored temperature; in programming mode it browses the parameter codes or decreases the displayed value.

 To turn ON or OFF the controller (if enabled)

### KEY COMBINATIONS:

 +  To lock & unlock the keyboard.

**SET** +  To enter in programming mode.

**SET** +  To return to the room temperature display.

## 2) Alarm Signals

### 2.1 Code Description

Message	Cause	Outputs
"P1"	Room probe failure	Compressor output acc. to par. "Con" and "COF"
"HA"	Maximum temperature alarm	Outputs unchanged.
"LA"	Minimum temperature alarm	Outputs unchanged.
"CA"	Serious external alarm (i1F=bAL)	All outputs OFF.

## 2.2 Alarm Recovery

Probe alarms P1”, start a few seconds after the fault in the related probe; they automatically stop a few seconds after the probe restarts normal operation. Check connections before replacing the probe. Temperature alarms “HA”, “LA” automatically stops as soon as the temperature returns to normal value. Alarm “CA” (with i1F=PAL) recovers only by switching off and on the instrument.

### 3) Temperature Set-Point

#### 3.1 How to see the set-point

1. Push and immediately release the SET key: the display will show the Set-point value;
2. Push and immediately release the SET key or wait for 5 seconds to display the probe value again.

#### 3.2 How to change the set-point

1. Push the SET key for more than 3 seconds to change the Set point value;
2. The value of the set point will be displayed and the “°C” or “°F” LED starts blinking;
3. To change the Set value, push the keys ▲ or ▼ arrows within 10s.
4. To memorize the new set point value, push the SET key again or wait 10s.

### 4) Humidity Adjustment

The parameter **Fon** is used to modulate the humidity in the wine cabinet. The higher value of **Fon**, the higher relative humidity will be.

1. Press the **Set** + ▼ keys for 3 sec. (the “°C” or “°F” LED starts blinking).
2. Release the keys, then push again the **Set** + ▼ keys for more than 7sec, the **Pr2** label will be displayed immediately followed from the **HY** parameter.
3. Select the required parameter **Fon** by up or down keys ▲ ▼.
4. Press the “**SET**” key to display its value.
5. Use up or down keys ▲ ▼ to change its value.
6. The default value is 0, change high or low value to maintain high or low humidity.
7. Press “**SET**” to store the new value.
8. **To exit:** Press **SET** + ▲ or wait 15sec without pressing a key.

### 5) Manual Defrost

Push the DEF key for more than 2 seconds and a manual defrost will start.

## Care Guide

### **! WARNING**




Always check wiring harness connections before initiating any test procedures.

Disconnect electric power from the appliance before performing any maintenance or repairs.

Voltage checks should be made by inserting meter probes beside the wires in the connector blocks with the electric power source on and the connector block plugged in.

Resistance checks should be made on components with the electric power off and the connector block disconnected.

### I. Component Identification



1. TOP HOUSING
2. BOTTOM HOUSING
3. REFRIGERATION SYSTEM
4. FANS & HOUSINGS
5. INSULATION FOAM
6. DIGITAL CONTROLLER


**Fig. 4.1 Exploded View**

## II. Condenser Coil Cleaning

- The condenser coil is on the ambient air intake side of the cooling unit.
- Clean the condenser coil regularly. Coil may need to be cleaned at least every 6 months.
- Unplug the unit or disconnect power.
- Use a condenser brush or a vacuum cleaner with an extended attachment to clean the coil when it is dusty or dirty.
- Plug the unit or reconnect power.

## III. Moisture Removing

- Remove the extra condensate if it is accumulated in the wine cabinet at high humidity condition.



## Troubleshooting

This Troubleshooting Chart is not prepared to replace the training required for a professional refrigeration service person, not is it comprehensive

### Troubleshooting Chart

Complaint	Possible Causes	Response
<b>1. Unit not running</b>		
	<ul style="list-style-type: none"> <li>a. Power cord unplugged</li> <li>b. No power to unit</li> <li>c. Incorrect or loose wirings</li> <li>d. Low voltage</li> <li>e. Defrost light blinking</li> <li>f. Compressor light blinking</li> <li>g. Setting higher than ambient temperature</li> <li>h. Differential too high</li> </ul>	<ul style="list-style-type: none"> <li>a. Check for power cord plug</li> <li>b. Check power at receptacle &amp; fuses</li> <li>c. Check all wirings and connections</li> <li>d. Contact an authorized electrician</li> <li>e. Unit is under defrost mode</li> <li>f. Unit waits for anti-short cycle delay</li> <li>g. Lower temperature setting</li> <li>h. Decrease the value as to 4 °F</li> </ul>
<b>2. Fan running almost continually</b>		
	<ul style="list-style-type: none"> <li>a. Post-compressor fan running mode for humidity modulation</li> </ul>	<ul style="list-style-type: none"> <li>a. See 4) to set FON = 0</li> </ul>
<b>3. Temperature fluctuating</b>		
	<ul style="list-style-type: none"> <li>a. Air sensor</li> </ul>	<p>a. When using an air sensor, the wine bottle temperature is mainly controlled by the average air temperature. If the set-point is 55°F with the differential 4F, the cooling unit turns on at 59°F of air temperature and turns off at 55°F of air temperature. The average air temperature is 57°F, and then the wine temperature is around 57+/-0.5°F. The air is light enough to change so quickly that it maintains relatively constant average temperature that would prevent wine bottle temperature from varying.</p>
<b>4. Temperature too high</b>		
	<ul style="list-style-type: none"> <li>a. Setting too high</li> <li>b. Improper cabinet seals</li> <li>c. Cabinet too large</li> <li>d. Ambient temperature too high</li> <li>e. Exhaust too close to wall or ceiling</li> <li>f. Malfunctioning fans</li> <li>g. Improper evaporator or condenser airflow</li> </ul>	<ul style="list-style-type: none"> <li>a. Lower setting</li> <li>b. Check for gasket and door opening</li> <li>c. Check for excessive size</li> <li>d. Check for installation location</li> <li>e. Leave 6" clearance between the exhaust side and the wall or ceiling; leave 4" clearance for the fresh-air supply side; leave 2" for the other sides</li> <li>f. Check for both evaporator and condenser fans</li> <li>g. Check for air restrictions</li> </ul>

<ul style="list-style-type: none"> <li>h. Dirty Condenser</li> <li>i. Iced evaporator</li> <li>j. Low voltage</li> <li>k. Operating 60 Hz unit at 50Hz</li> <li>l. Sealed system problem</li> </ul> <ul style="list-style-type: none"> <li>m. Undercharge or overcharge</li> <li>n. Air sensor contacting the evaporator</li> </ul>	<ul style="list-style-type: none"> <li>h. Clean condenser</li> <li>i. Defrost and reset temperature</li> <li>j. Check power supply</li> <li>k. Use proper 60 Hz</li> <li>l. Call service for checking loss of refrigerant or restrictions</li> </ul> <ul style="list-style-type: none"> <li>m. Call service to add or remove refrigerant</li> <li>n. Move the air sensor away from the evaporator</li> </ul>
---	--

**5. Unit running too long or continually**

<ul style="list-style-type: none"> <li>a. Setting too low</li> <li>b. Improper cabinet seals</li> <li>c. Exhaust too close to wall or ceiling</li> </ul> <ul style="list-style-type: none"> <li>d. Cabinet too large</li> <li>e. Ambient temperature high &gt; 80 F</li> <li>f. Improper evaporator or condenser airflow</li> <li>g. Dirty Condenser</li> <li>h. Iced evaporator</li> <li>i. Malfunctioning fans</li> </ul> <ul style="list-style-type: none"> <li>j. Low voltage</li> <li>k. Operating 60 Hz unit at 50Hz</li> <li>l. Sealed system problem</li> </ul> <ul style="list-style-type: none"> <li>m. Undercharge or overcharge</li> </ul>	<ul style="list-style-type: none"> <li>a. Increase the setting</li> <li>b. Check for gasket and door opening</li> <li>c. Leave 6" clearance between the exhaust side and the wall or ceiling; leave 4" clearance for the fresh-air supply side; leave 2" for the other sides</li> </ul> <ul style="list-style-type: none"> <li>d. Check for excessive size or increase setting</li> <li>e. Check for installation location or increase setting</li> <li>f. Check for air restrictions</li> </ul> <ul style="list-style-type: none"> <li>g. Clean condenser</li> <li>h. Defrost and reset temperature</li> <li>i. Check for both evaporator and condenser fans</li> <li>j. Check power supply</li> <li>k. Use proper 60 Hz</li> <li>l. Call service for checking loss of refrigerant or restrictions</li> </ul> <ul style="list-style-type: none"> <li>m. Call service to add or remove refrigerant</li> </ul>
---	---

**6. "HA" maximum temperature alarm blinking or beeping**

<ul style="list-style-type: none"> <li>a. Ambient temperature too high</li> <li>b. Improper cabinet seals</li> <li>c. Cabinet too large</li> <li>d. Improper evaporator or condenser airflow</li> <li>e. Dirty Condenser</li> <li>f. Iced evaporator</li> <li>g. Malfunctioning fans</li> </ul> <ul style="list-style-type: none"> <li>h. Low voltage</li> <li>i. Operating 60 Hz unit at 50Hz</li> <li>j. Sealed system problem</li> </ul> <ul style="list-style-type: none"> <li>k. Undercharge or overcharge</li> </ul> <ul style="list-style-type: none"> <li>l. Exhaust too close to wall or ceiling</li> </ul>	<ul style="list-style-type: none"> <li>a. Check for installation location</li> <li>b. Check for gasket and door opening</li> <li>c. Check for excessive size</li> <li>d. Check for air restrictions</li> </ul> <ul style="list-style-type: none"> <li>e. Clean condenser</li> <li>f. Defrost and reset temperature</li> <li>g. Check for both evaporator and condenser fans</li> <li>h. Check power supply</li> <li>i. Use proper 60 Hz</li> <li>j. Call service for checking loss of refrigerant or restrictions</li> </ul> <ul style="list-style-type: none"> <li>k. Call service to add or remove refrigerant</li> </ul> <ul style="list-style-type: none"> <li>l. Leave 6" clearance between the exhaust and the wall or ceiling; leave 4" clearance for the fresh-air supply side; leave 2" for the other sides</li> </ul>
---	---

<b>7. Compressor stopping and starting but short running time</b>		
	<ul style="list-style-type: none"> <li>a. Temperature setting too high</li> <li>b. Incorrect voltage</li> <li>c. Failed thermistor</li>   <li>d. Failed components</li>   <li>e. Improper condenser airflow</li> <li>f. Dirty condenser</li> <li>g. Overcharge of refrigerant</li> <li>h. Discharge or suction pressure too high</li> </ul>	<ul style="list-style-type: none"> <li>a. Set 55 to 60 °F</li> <li>b. Check for voltage</li> <li>c. Check thermistor by placing it in ice water and measuring resistance</li> <li>d. Check compressor windings, start relay and overload protector.</li> <li>e. Check for condenser fan</li> <li>f. Clean condenser</li> <li>g. Call service for removing refrigerant</li> <li>h. Call service for OEM information</li> </ul>
<b>8. Fan motor running but compressor not running</b>		
	<ul style="list-style-type: none"> <li>a. Incorrect power supply</li> <li>b. Incorrect or loose wirings</li> <li>c. Failed components</li>   <li>d. Post-compressor fan running mode</li>   <li>e. Liquid refrigerant in the compressor</li> </ul>	<ul style="list-style-type: none"> <li>a. Check for proper voltage</li> <li>b. Check all wirings and connections</li> <li>c. Check start relay, start capacitor, overload protector, compressor.</li> <li>d. Check for fan running time FON.</li> <li>e. Call service for OEM information.</li> </ul>
<b>9. Compressor running but fan not running</b>		
	<ul style="list-style-type: none"> <li>a. Fan blade stuck</li> <li>b. Incorrect or loose wirings</li> <li>c. Failed motors</li> </ul>	<ul style="list-style-type: none"> <li>a. Check for proper clearance</li> <li>b. Check all wirings</li> <li>c. Call service for checking open or shorted windings</li> </ul>
<b>10. No cooling but compressor and fan running</b>		
	<ul style="list-style-type: none"> <li>a. Evaporator airflow restriction</li> <li>b. Refrigerant leakage</li> <li>c. Refrigeration system restriction</li> </ul>	<ul style="list-style-type: none"> <li>a. Check for airflow through evaporator</li> <li>b. Check for loss of refrigerant</li> <li>c. Call service for checking restrictions</li> </ul>
<b>11. Evaporator Icing</b>		
	<ul style="list-style-type: none"> <li>a. Evaporator air flow restriction</li> <li>b. Not stopping due to air leak, high ambient temperature or low setting</li> <li>c. Low ambient temperature</li> <li>d. Bad thermostat or sensor</li> <li>e. Refrigerant leaking</li> <li>f. Capillary tube blockage</li> </ul>	<ul style="list-style-type: none"> <li>a. Check for fans</li> <li>b. Check for seal, door opening, ambient temperature and setting</li> <li>c. Defrost unit</li> <li>d. Check for thermostat and sensor</li> <li>e. Check for sealed system leakage</li> <li>f. Check for low side pressure</li> </ul>
<b>12. House circuit tripping</b>		
	<ul style="list-style-type: none"> <li>a. Incorrect fuse or breaker</li> <li>b. Incorrect wirings</li> <li>c. Failed components</li> </ul>	<ul style="list-style-type: none"> <li>a. Check for proper fuse or breaker</li> <li>b. Check for wirings and connections</li> <li>c. Call service</li> </ul>
<b>13. Noisy operation</b>		
	<ul style="list-style-type: none"> <li>a. Mounting area not firm</li> <li>b. Loose parts</li>   <li>c. Compressor overloaded due to high ambient temperatures or airflow restriction</li> <li>d. Malfunctioning components</li> </ul>	<ul style="list-style-type: none"> <li>a. Add support to improve installation</li> <li>b. Check fan blades, bearings, cabinet washers, tubing contact and loose screws.</li> <li>c. Check for airflow blockage</li>   <li>d. Call service for checking internal loose, inadequate lubrication and incorrect wirings</li> </ul>

# Wiring Diagram




Fig. 6.1 WIRING DIAGRAM

## Customer Support

If you still have problems, please contact us at:

Vinotemp International  
17631 South Susana Road  
Rancho Dominguez, CA 90221  
Tel: (310) 886-3332  
Fax: (310) 886-3310  
Email: [info@vinotemp.com](mailto:info@vinotemp.com)

# Warranty

**Thank you for choosing a Vinotemp wine cabinet.**

Please enter the complete model and serial numbers in the space provided:

Model \_\_\_\_\_  
Serial No. \_\_\_\_\_

Attach your purchase receipt to this owner's manual.

## 1. Limited Warranty

VINOTEMP warrants its products to be free from defects due to workmanship or materials under normal use and service, for twelve months after the initial sale. If the product is defective due to workmanship or materials, is removed within twelve months of the initial sale and is returned to VINOTEMP, in the original shipping carton, shipping prepaid, VINOTEMP will at its option, repair or replace the product free of charge. Additionally VINOTEMP warrants all parts to be free from defects for a period of sixty months after initial sale.

This warranty constitutes the entire warranty of the VINOTEMP with respect to its products and is in lieu of all other warranties, express or implied, including any of fitness for a particular purpose. In no event shall VINOTEMP be responsible for any consequential damages what is so ever. Any modification or unauthorized repair of VINOTEMP products shall void this warranty.

## Service under Warranty

This service is provided to customers within the continental UNITED STATES only. VINOTEMP cooling units are warranted to produce the stated number of BTU/H. While every effort has been made to provide accurate guidelines, VINOTEMP can not warranty its units to cool a particular enclosure.

In case of failure, VINOTEMP cooling units must be repaired by the factory or its authorized agent. Repairs or modifications made by anyone else will void the warranty.

Should a VINOTEMP cooling unit fail, contact the dealer for instructions. Do not return the unit to the factory without authorization from VINOTEMP. If the unit requires repair, re-pack it in the original shipping carton and return it to the factory, shipping prepaid. VINOTEMP will not accept COD shipments. If the unit

is determined to be faulty and is within the twelve month warranty period VINOTEMP will, at its discretion, repair or replace the unit and return it free of charge to the original retail customer. If the unit is found to be in good working order, or beyond the initial twelve month period, it will be returned freight collect.

## **2. Limitation of Implied Warranty**

**VINOTEMP'S SOLE LIABILITY FOR ANY DEFECTIVE PRODUCT IS LIMITED TO, AT OUR OPTION, REPAIRING OR REPLACING OF UNIT.**

**VINOTEMP SHALL NOT BE LIABLE FOR:  
DAMAGE TO OTHER PROPERTY CAUSED BY ANY DEFECTS IN THE UNIT,  
DAMAGES BASED UPON INCONVENIENCE, LOSS OF USE OF THE UNIT,  
LOSS OF TIME OR COMMERCIAL LOSS, ANY OUTER DAMAGES,  
WHETHER INCIDENTAL, CONSEQUENTIAL OR OTHERWISE.**

**THIS WARRANTY IS EXCLUSIBE AND IS IN LIEU OF ALL OTHER  
WARRANTIES, EXPRESSED OR INPLIED, INCLUDING BUT NOT LIMITED  
TO, IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A  
PARTICULAR PURPOSE.**

While great effort has been made to provide accurate guidelines VINOTEMP cannot warrant its units to properly cool a particular enclosure. Customers are cautioned that enclosure construction, unit location and many other factors can affect the operation and performance of the unit. There for suitability of the unit for a specific enclosure or application must be determined by the customer and cannot be warranted by VINOTEMP.